

DUAL OUTPUT PROPORTIONAL CONTROLLER OPERATING INSTRUCTION

SY-DPCA-C-2 : Case with DIN-35 Rail Clamps SY-DPCA-P-2 : PCB Only

MODEL SPEC.

Model	SY-DPCA-C-2, SY-DPCA-P-2
Operating Voltage	9 ~ 32VDC
Voltage Tolerance	5%
Input Signal Options	0~5V, 0~10V, 4~20mA, RS485
Output Current	3A max. for each output
PWM Frequency	70~1000Hz
Dither Frequency	70~500Hz


Model	SY-DPCA-C-2, SY-DPCA-P-2
Ramp Up and Down	0.1 ~ 5.0s
Reference Voltage	5V (max. current 5mA)
Communication Interface	RS485
Communication Protocol	Modbus RTU
Operating Conditions	-20 ~ 60°C

CONNECTIONS AND DIMENSIONS





Wiring Instruction

1	GND	Ground (VS+ / CMD)
2	VS+	Power source
3	CoilA+	Coil A output+
4	CoilA-	Coil A output-
5	CoilB+	Coil B output+
6	CoilB-	Coil B output-
7	CMD1	Command signal 1
8	CMD2	Command signal 2
9	5Vref	5V reference voltage
10	D+	RS485+
11	D-	RS485-

► SY-DPCA-P-2



► SY-DPCA-C-2



(Unit : mm)

OPERATING MODE

	MODE 1	MODE 2	MODE 3
LED Color	Orange	Green	Red
Description	Single Command vs. Single Output	Dual Indep. Command vs. Dual Indep. Output	Single Command vs. Dual Linked Output

SETTING THE PARAMETERS

- At main screen, long press **SET** to open function menu.
 - Use **UP** and **DOWN** to select function, then press **SET**.
 - Use **UP** and **DOWN** to adjust function value, then press **SET** to setup and return to function menu.
 - After setup, long press **SET** to return main screen.
 - Return to main screen by pushing **SET** button for 2s manually or idling for 60s.
- ⚠ Save : After setup, select *P5R* function and adjust the value to "5" to save changes.
- ⚠ Default : Select *P-r-F* function and adjust the value to "5" to factory reset.

FUNCTION TABLE

No.	Function	Display	Default Value	Adjustment Range	Unit	Description
Coil A						
1	Max. output current	<i>A IH</i>	1.00	0.20~3.00	A	adj. unit 0.01A
2	Min. output current	<i>A IL</i>	0.00	0.00~1.00	A	adj. unit 0.01A
3	Ramp up time	<i>A rU</i>	0.1	0.1~5.0	s	adj. unit 0.1s
4	Ramp down time	<i>A rD</i>	0.1	0.1~5.0	s	adj. unit 0.1s
5	Command deadband	<i>A cD</i>	2	0~5	%	adj. unit 1%
6	Command source	<i>A In</i>	PA1	PA1/481		PA1:CMD1 ; 481:485 control-1
7	PWM frequency	<i>A PF</i>	140	70~1000	Hz	adj. unit 10Hz
8	Dither frequency	<i>A DF</i>	140	70~500	Hz	adj. unit 10Hz
9	Dither Amplitude	<i>A dA</i>	0	0~25	%	adj. unit 1%
Coil B						
10	Max. output current	<i>b IH</i>	1.00	0.20~3.00	A	adj. unit 0.01A
11	Min. output current	<i>b IL</i>	0.00	0.00~1.00	A	adj. unit 0.01A
12	Ramp up time	<i>b rU</i>	0.1	0.1~5.0	s	adj. unit 0.1s
13	Ramp down time	<i>b rD</i>	0.1	0.1~5.0	s	adj. unit 0.1s
14	Command deadband	<i>b cD</i>	2	0~5	%	adj. unit 1%
15	Command source	<i>b In</i>	PA2	non/PA1/ PA2/481/482		non:disable Coil B Output ; PA1:CMD1 ; PA2:CMD2 ; 481:485 control-1 ; 482:485 control-2
16	PWM frequency	<i>b PF</i>	140	70~1000	Hz	adj. unit 10Hz
17	Dither frequency	<i>b DF</i>	140	70~500	Hz	adj. unit 10Hz
18	Dither Amplitude	<i>b dA</i>	0	0~25	%	adj. unit 1%


No.	Function	Display	Default Value	Adjustment Range	Unit	Description
Others						
19	CMD1 selection	<i>PR1</i>	10	10/5/420		10:0~10V ; 5:0~5V ; 420:4~20mA
20	CMD2 selection	<i>PR2</i>	10	10/5/420		10:0~10V ; 5:0~5V ; 420:4~20mA
21	Display type	<i>PdS</i>	0	0~4		0: Coil A current ; 1: Coil A command ; 2: Coil B current ; 3: Coil B command ; 4: display off
22	Save setup	<i>PSA</i>	0	0~5		When adjusting to 5, save all changes to controller
23	Factory reset	<i>PrF</i>	0	0~5		When adjusting to 5, factory reset the controller
24	Clear error code	<i>PcL</i>	0	0~5		When adjusting to 5, clear the E31 error code
RS485 *1						
25	Device address	<i>Adr</i>	001	001~247		Changes to the device address and baud rate will take effect only after saving (PSA) and rebooting the device.
26	Baud rate	<i>bdr</i>	19.2	4.8/9.6/19.2/ 38.4/57.6	K	

*1. The controller interfaces directly with RS485 MODBUS RTU compliant devices via Terminals 10 and 11. To use our PC software for setup and monitoring, a USB-to-RS485 converter is required (sold separately).

Using a USB-RS485 converter, you can operate and configure parameters via the PC software provided by our company. Please mail us to get the PC software : info@steadmachinery.com.tw.





1. Ramp up/down Time settings



1. Output Current and Command deadband settings



MODE 1 / MODE 2 :

Single Output vs. Single Command / Dual Indep. Output vs. Dual Indep. Command Source



MODE 3 :

Single Command vs. Dual Linked Output



ERROR CODE

Error Code	Error Description	Clear Error Code
Coil A		
E 10	4-20mA signal open	For error code E 10, E 11, E 12, controller will detect troubleshooting and clear the error code automatically.
E 11	4-20mA signal overload	
E 12	Coil open	
E 13	Coil short	For error code E 13, after troubleshooting, it is necessary to adjust function P _{CL} or reboot to clear the error code.
Coil B		
E 20	4-20mA signal open	For error code E 20, E 21, E 22, controller will detect troubleshooting and clear the error code automatically.
E 21	4-20mA signal overload	
E 22	Coil open	
E 23	Coil short	For error code E 23, after troubleshooting, it is necessary to adjust function P _{CL} or reboot to clear the error code.

WARNING

1. Install the controller and Coil only when the power is off.
2. According to European standards EN-982, the electrical output signal of the controller (e.g. reference voltage) must not be directly used to activate safety functions, like to switch-ON/OFF the machine's safety components.



This product has been designed and tested to meet specific standards outlined in the European Electromagnetic Compatibility Directive (EMC)2014/30/EU.
Emission: EN 61000-6-4:2019
Immunity: EN 61000-6-2:2019: EN 61000-4-2:2009, EN 61000-4-3:2020, EN 61000-4-8:2010
Certificate No. NE1105240044

COMMUNICATION PARAMETERS

The default Modbus RS485 communication parameters are as follows (some can be adjusted via the control panel) :

Parameter	Settings	Remarks
Device Address	1(01h) ~ 247(F7h)	Default : 1
Baud Rate	4800, 9600, 19200, 38400, 57600	Default : 19200
Data Bits	8	Fixed
Parity	None (N)	Fixed
Stop Bits	1	Fixed
Protocol Mode	RTU	Fixed
Supported Function codes	03h (Read), 06h (Write)	Others not supported

REGISTER ADDRESS TABLE

The following Modbus registers are supported :

Register Address	Name	R/W	Description	Example	
				Decimal	HEX
Real-time Monitor					
0000H	Coil A Output Current	R	Unit: 0.01A (e.g., 67 → 0.67A)	67	0043h
0001H	Coil A Input Command	R	Unit: 0.1% (e.g., 356 → 35.6%)	356	0164h
0002H	Coil A Status	R	0: Normal; 1: Current Signal Broken; 2: Overload; 3: Coil Open; 4: Coil Short	0	0000h
0003H	Coil B Output Current	R	Unit: 0.01A (e.g., 67 → 0.67A)	67	0043h
0004H	Coil B Input Command	R	Unit: 0.1% (e.g., 356 → 35.6%)	356	0164h
0005H	Coil B Status	R	0: Normal; 1: Current Signal Broken; 2: Overload; 3: Coil Open; 4: Coil Short	0	0000h
Common Parameters					
0006H	Command(1) Selection	R/W	0: 0~10V (Default); 1: 0~5V; 2: 4~20mA	2	0002h
0007H	Command(2) Selection	R/W	0: 0~10V (Default); 1: 0~5V; 2: 4~20mA	2	0002h
0008H	Panel Display Mode	R/W	0: Coil A Current(Default); 1: Coil A Command; 2: Coil B Current; 3: Coil A Command; 4: No Display	0	0000h
0009H	485 Command(1)	R/W	0~100%, Unit: 1% (e.g., 80 → 80%)	80	0050h
000AH	485 Command(2)	R/W	0~100%, Unit: 1% (e.g., 80 → 80%)	80	0050h
000BH	Device Address	R/W	1(01h)~247(F7h) (Change will be applied after reboot)	1	0001h
000CH	Baud Rate	R/W	0: 4800; 1: 9600; 2: 19200; 3: 38400; 4: 57600 (Change will be applied after reboot)	2	0002h
000DH	Factory Reset	R/W	Write 5 to factory reset addresses 0003H~0027H (Change will be applied after reboot)	5	0005h

Register Address	Name	R/W	Description	Example	
				Decimal	HEX
Coil A Section					
000EH	Input Selection	R/W	0: Command(1); 1: 485 Command(1)	0	0000h
000FH	Feedback Command	R/W	0: off; 1: Command(1); 2: Command(2)	0	0000h
0010H	Max. Output Current	R/W	0.2~3.00A, Unit: 0.01A (e.g., 300 → 3.00A)	300	012Ch
0011H	Min. Output Current	R/W	0.2~3.00A, Unit: 0.01A (e.g., 300 → 3.00A)	100	0064h
0012H	Ramp Up Time	R/W	0.1~5.0s, Unit: 0.1s (e.g., 50 → 5.0s)	50	0032h
0013H	Ramp Down Time	R/W	0.1~5.0s, Unit: 0.1s (e.g., 10 → 1.0s)	10	000Ah
0014H	Command Deadband	R/W	0~5%, Unit: 1% (e.g., 5 → 5%)	5	0005h
0015H	PWM Frequency	R/W	70~1000Hz, Unit: 10Hz (e.g., 35 → 350Hz)	35	0023h
0016H	Dither Frequency	R/W	70~500Hz, Unit: 10Hz (e.g., 35 → 350Hz)	35	0023h
0017H	Dither Amplitude	R/W	0~25%, Unit: 1% (e.g., 10 → 10%)	10	000Ah
Coil B Section					
0018H	Input Selection	R/W	0: No Output; 1: Command(1); 2: Command(2); 3: 485 Command(1); 4: 485 Command(2)	2	0002h
0019H	Feedback Command	R/W	0: off; 1: Command(1); 2: Command(2)	0	0000h
001AH	Max. Output Current	R/W	0.2~3.00A, Unit: 0.01A (e.g., 300 → 3.00A)	300	012Ch
001BH	Min. Output Current	R/W	0.2~3.00A, Unit: 0.01A (e.g., 300 → 3.00A)	100	0064h
001CH	Ramp Up Time	R/W	0.1~5.0s, Unit: 0.1s (e.g., 50 → 5.0s)	50	0032h
001DH	Ramp Down Time	R/W	0.1~5.0s, Unit: 0.1s (e.g., 10 → 1.0s)	10	000Ah
001EH	Command Deadband	R/W	0~5%, Unit: 1% (e.g., 5 → 5%)	5	0005h
001FH	PWM Frequency	R/W	70~1000Hz, Unit: 10Hz (e.g., 35 → 350Hz)	35	0023h
0020H	Dither Frequency	R/W	70~500Hz, Unit: 10Hz (e.g., 35 → 350Hz)	35	0023h
0021H	Dither Amplitude	R/W	0~25%, Unit: 1% (e.g., 10 → 10%)	10	000Ah
PID Parameters					
0022H	FB Command(A) P	R/W	0~1000	80	0050h
0023H	FB Command(A) I	R/W	0~1000	80	0050h
0024H	FB Command(A) D	R/W	0~1000	80	0050h
0025H	FB Command(B) P	R/W	0~1000	80	0050h
0026H	FB Command(B) I	R/W	0~1000	80	0050h
0027H	FB Command(B) D	R/W	0~1000	80	0050h

ERROR HANDLING

If an error occurs, the controller responds with:

1. Error Types:

- Unsupported function code (e.g., 04h)
- Invalid register address (e.g., 000EH out of range)
- Data value out of range (e.g., writing 400 to 0008H)
- For other errors such as CRC or frame length errors, controller will discard the message without responding.

2. Error Response Format:

- Original function code **+128 (80h)**
- Error code: **01h** (indicates the error type)

3. Example:

- Host request 01 04 0008 0001 (invalid function code 04h)
- Controller response 01 84 01 (84h = 80h + 04h, 01h = error code)

COMMUNICATION EXAMPLES

Example 1: Reading Data

Read "Coil A Output Current (0000H)" and "Coil A Input Command (0001H)" from device address 01h.

Host Request

01 03 0000 0002 C40B

- 01: Device address
- 03: Function code (Read)
- 0000: Start address (0000H)
- 0002: Read 2 registers
- C40B: CRC checksum

Controller Response

01 03 04 006E 0212 1A83

- 01: Device address
- 03: Function code (Read)
- 04: Byte count (4 bytes)
- 006E: 0000H value (0x006E = 110 → 1.10A)
- 0212: 0001H value (0x0212 = 530 → 53.0%)
- 1A83: CRC checksum

Example 2: Writing Data

Set "Coil A PWM Frequency (0014H)" to 250Hz for device address 0Eh.

Host Request

0E 06 0014 0019 2607

- 0E: Device address
- 06: Function code (Write)
- 0014: Target address (0014H)
- 0019: Value (0x0019 = 25 → 250Hz)
- 2607: CRC checksum

Controller Response

0E 06 0014 0019 2607

- Echoes the request to confirm successful write.

PC COMMUNICATION SOFTWARE

Using a USB-RS485 converter, you can operate and configure parameters via the PC software provided by our company.

Installation Guide

- Step 1 : Insert the converter into the USB port on the PC.
- Step 2 : Install the converter driver (only required for the first use).
- Step 3 : Connect the controller and the converter.
- Step 4 : Launch the PC software. Please mail us : info@steedmachinery.com.tw.
- Step 5 : Follow the instructions within the software to proceed.



NOTES

1. **Timeout** : Ensure **>10ms** idle time between messages.
2. **CRC Checksum** : Mandatory for all messages (use standard Modbus RTU CRC calculation).
3. **Address Range** : Only 0000H~000DH registers are valid.
4. All parameters configured through Modbus will be saved automatically.